

WC combi with washbasin

Installation manual

- Before you begin, carefully inspect the new toilet for visible damage or manufacturing faults.
- Read the installation manual before proceeding to installation.



1.

- Install a flush (drain) valve connected to the cistern through the pop up waste with the control button.



2.

- Connect the plastic hose to the mixer

3.



- Install the mixer tap/ cold water tap on the basin.

4.



- Install the drain.

5.

- Connect the inlet valve to the cold water hose and fit it into the hole in the bottom of the cistern closer to the WC pan. (You can lay the washbasin across the cistern.)



6.

- Connect the hot water hose to the grommet through the tank through the bottom of the tank (opening closer to the wall) and attach.



7.

- Connect the hot water hose to the grommet which goes through the cistern through the bottom of the cistern (the hole closer to the wall) and fasten it.
- Connect the angle valve for cold water and inlet valve with a flexible hose (3/8" / 1/2").
- Connect the angle valve for hot water and the grommet which goes through the cistern with a flexible hose (3/8" / 1/2").

8.

- Place the basin on the cistern.